


From time to time the door(s) can become mis-aligned. It is a simple fix and can be done easily.

Please note that only light pressure is needed to perform this alignment so as to not damage the door.

If the bottom of the door is protruding away from the cart please follow the recommendation pictured below. If the opposite is the case, the door is protruding for the cart, simply reverse the procedure.



PLEASE NOTE ONLY LIGHT PRESSURE IS REQUIRED